



Application Guide for Light Commercial Vehicles

Make	Model	Stud Configuration	Nut Size	PCD	Wheel Sentry Kit
Citroen	Berlingo	4	17mm (LR)	108mm	21.2179
Citroen	Dispatch	5	17mm (LR)	108mm	21.2173
Citroen	Relay	5	21mm (LR)	118mm	21.2162
Fiat	Doblo	5	17mm (LR)	98mm	21.2176
Fiat	Ducato	5	21mm (LR)	118mm	21.2162
Fiat	Fiorino	4	17mm (LR)	98mm	21.2178
Fiat	Punto	4	17mm (LR)	98mm	21.2178
Fiat	Scudo	5	17mm	108mm	21.2173
Ford	Ranger	6	21mm	5.5"	21.2085
Ford	Transit	5	21mm	160mm	21.2076
Ford	Transit Chassis Cab	6	21mm	180mm	21.2097
Ford	Transit Connect	5	19mm	108mm	21.2074
Ford	Transit Custom	5	21mm	160mm	21.2076
Ford	Fiesta	4	19mm	108mm	21.2159
Isuza	D-Max	6	19mm	5.5"	21.2088
Iveco	Daily	6	27mm	170mm	21.2150
Land Rover	Defender	5	27mm	6.5"	21.2049
Mercedes	Sprinter	6	19mm	130mm	21.2090
Mercedes	Sprinter	6	19mm	205mm	21.2100
Peugeot	Expert	5	17mm (LR)	108mm	21.2173
Peugeot	Partner	4	17mm (LR)	108mm	21.2179
Toyota	Hilux	6	21mm (LR)	5.5"	21.2085
Vauxhall	Corsa	4	19mm	100mm	21.2042
Vauxhall	Movano	5	19mm	130mm	21.2086
Vauxhall	Movano Chassis Cab	6	27mm	205mm	21.2050
Vauxhall	Vivaro	5	19mm	118mm	21.2044
Volkswagen	Caddy	5	17mm	112mm	21.2064
Volkswagen	Transporter	5	19mm	118mm	21.2044



**WE'RE RIGHT
BEHIND YOU®**

For more information on our products visit our website www.ate-uk.com
or alternatively call 01206 795949 / email sales@ate-uk.com